Revised Manual: Maximum working pressure 250 bar. Do not use a dowty seal on this gauge Do not use this gauge on a HPA Compressor

Thighten by hand. Do not overthighten

Digital Pressure Gauge 25mm std User's Manual

SEKHMET **KEY FEATURES**

- Incredible Accuracy: down to 1 bar
- Precision: +/-0.25%
- Super fast reaction time of 0.1 seconds
- 25mm diameter, compact size suitable for more PCP
- 0.63" LCD screen
- Rechargeable, more ECO friendly
- Long battery life, one charge can be used for 6 months 5-level real-time power display with low-power reminder

- TYPICAL USES Internal/External Regulator
- Adjustable Regulator
- Main Chamber/Pressure Tank



NAME & FUNCTION OF EACH PART





SEKHMET


INSTALLATION

SEKHMET Champion's Choice

■ Loose the original gauge and remove it from your air rifle, keep the original seal component as much as possible.

If the original seal is used. DO NOT use the Sekhmet seal again. the original seal is lost or damaged, there are two kinds of seal components you can choose from the Sekhmet box. *If the Sekhmet seals are used, ensure that the original seals have been thoroughly removed and clean the threads before installation.





• After aligning the gauge with the threaded fitting, rotate it to the end and apply a certain amount of force as needed to ensure that the gauge is fully seated against the seal. DO NOT overtighten the gauge, tighten the gauge by hand

OPERATION

The pressure gauge only has a one-touch button and has three interactive states:

 Power ON: Short touch, the upper left corner displays the barometric pressure reading in real-time with the unit bar.



- Battery Indicator: When the screen is on, long touch the area (less than 5 seconds) to switch from the pressure display to the battery display, the battery symbol lights up in the upper right corner, indicating the current battery range with 100%, 60%, 20%, 5%, and Lo 5 levels. Release the button to return to the pressure display interface. ** If held for more than 5 seconds, it will trigger a shutdown.
- Power OFF: Long touch for more than 5 seconds to shut
- Auto Power off: It will automatically turn off after 1 minute:



- Display Screen: Shows pressure in bar & battery level
- with battery icon
- Touch Buttons: Whole area can be touched
- Power Supply: Magnetic charging connector to USB cable
- Snubber: To protect pressure sensors and pressure gauges against pressure surges, if it is loose.

Vent Hole: Explosion-proof. DO NOT block this hole.

use a flat-blade screwdriver to tighten it

Manual.

safe direction.

!\ IMPORTANT

Warranty Information & Contact Details

ZERO. Please make sure the air inlet is clear.

SAFETY PRECAUTION

WARNING

2-year warranty. If you encounter any problems, please contact: sekhmetairgun@gmail.com

To ensure operator safety, use this instrument in conformance

with the directions and specifications given in this User's

Degassing your air rifle before installation Make sure the

Using Rubber aaskets could possibly block the air inlet due

to over-tightening, which may cause the gauge to read

airgun is unloaded, uncocked, ON SAFE and pointed in a

SEKHMET

Champion's Choice

SEKHMET Champion's Choice

When the actual battery level is between

When the actual battery level is between

When the actual battery level is between

20-5%, the battery level display shows 20.

battery icon and the battery level display

When the actual battery level is below 5%, the

shows 5 will blink three times, reminding you

60-20%, the battery level display shows 60.

100-60%, the battery level display shows 100.

CHARGING INSTRUCTIONS

SEKHMET Champion's Choice

SEKHMET

MEASUREMENT (mm)

SEKHMET Champion's Choice

SEKHMET Champion's Choice

■ Leakage: If the pressure gauge loses more than 10 bar of pressure

sekhmetonline.com sekhmetairgun@gmail.com

©2023 ORI Design Inc.

All specifications are subject to change without notice.


All sales subject to standard terms and conditions.

When the gauge is turned on, after the magnetic charging port is connected to the USB charging cable, the pressure display mode will automatically switch to the battery display mode, displaying the current battery level.

Pressure Range 15 - 250 bar ±0.25% FS over 10 C~ 40 C Accuracy ±0.5% FS over -10 °C ~ 80 °C Sampling Rate 10 HZ Repeatability Better than 0.5% Ingress Protection Display 0.63"LCD

1/8 BSPP

-5°C ~ 40°C



- When the gauge is turned off, after the magnetic charging port is connected to the USB charging cable, the screen will not wake up automatically.Please wake-up the gauge by short touch to check if the device is charging.
- Note: The battery is fully charged in approximately 60 minutes from 0% to 100%.

SPECIFICATION

Thread

Operating temperature

← Diameter 25 → Wrench Size 24 →

within 12 hours in a constant temperature state after replacing the Sekhmet pressure gauge, consider whether the sealing ring used in the pressure gauge is installed correctly. If it is confirmed that the installation is correct but there is no leakage point, you can use a balloon to wrap the pressure gauge to observe whether the balloon gradually expands.

■ Note: the pressure gauge is waterproof and not water-resistant. Do NOT immerse it in water to observe bubbles.

■ Unable to Turn On: After receiving the gauge for the first time, charge it for 1 hour to ensure that the battery is full. If it still can not turn on after 2 hours of charging, please contact Sekhmet official customer service or the dealer where you purchased it promptly. Do NOT open the pressure gauge panel yourself, as this may be dangerous.

When the actual battery level approaches 0%, the battery icon and "Lo" will blink three times, and the gauge will automatically turn off. Please charge it in time.

SEKHMET